



40V batteri	Opladningstid (til 100%)	
9072993: ECHO 40V 2Ah, LBP-36-80	Med oplader LC3604 (9072995): 100 minutter	
9072994: ECHO 40V 4Ah, LBP-36-150	Med oplader LC3604 (9072995): 170 minutter	

56V batteri	Opladningstid (til 100%)	
9073057: ECHO 56V 2,3Ah, LBP-50-150	Med oplader LCJQ-560 (9073059): 47 minutter Med lynlader LCJU-560 (9073060): 42 minutter	
9073058: ECHO 56V 4,5Ah, LBP-50-250	Med oplader LCJQ-560 (9073059): 89 minutter Med lynlader LCJU-560 (9073060): 57 minutter	

40V redskaber	Kompatibelt batteri	
9072996: ECHO løvblæser DPB-310	9072993: ECHO 40V 2Ah, LBP-36-80, 9072994: ECHO 40V 4Ah, LBP-36-150	
9072997: ECHO hækkeklipper DHC-310	9072993: ECHO 40V 2Ah, LBP-36-80, 9072994: ECHO 40V 4Ah, LBP-36-150	
9072998: ECHO stangsav DPPF-310	9072993: ECHO 40V 2Ah, LBP-36-80, 9072994: ECHO 40V 4Ah, LBP-36-150	
9072999: ECHO stangklipper DHCA-310	9072993: ECHO 40V 2Ah, LBP-36-80, 9072994: ECHO 40V 4Ah, LBP-36-150	
9073000: ECHO græstrimmer DSRM-310	9072993: ECHO 40V 2Ah, LBP-36-80, 9072994: ECHO 40V 4Ah, LBP-36-150	
9073001: ECHO kædesav DCS-310	9072993: ECHO 40V 2Ah, LBP-36-80, 9072994: ECHO 40V 4Ah, LBP-36-150	

56V redskaber	Kompatibelt batteri	
9073048: ECHO topkappersav DCS-2500T	9073057: ECHO 56V 2,3Ah, LBP-50-150	
9073049: ECHO kædesav DCS-3500	9073057: ECHO 56V 2,3Ah, LBP-50-150; 9073058: ECHO 56V 4,5Ah, LBP-50-250	
9073050: ECHO stangsav DPPT-2600LW	9073057: ECHO 56V 2,3Ah, LBP-50-150; 9073058: ECHO 56V 4,5Ah, LBP-50-250	
9073051: ECHO løvblæser DPB-2500	9073057: ECHO 56V 2,3Ah, LBP-50-150; 9073058: ECHO 56V 4,5Ah, LBP-50-250	
9073052: ECHO hækkeklipper DHC-2200R	9073057: ECHO 56V 2,3Ah, LBP-50-150	
9073053: ECHO stangklipper DHCA-2600HD	9073057: ECHO 56V 2,3Ah, LBP-50-150; 9073058: ECHO 56V 4,5Ah, LBP-50-250	
9073054: ECHO græstrimmer DSRM-2600/U	9073057: ECHO 56V 2,3Ah, LBP-50-150; 9073058: ECHO 56V 4,5Ah, LBP-50-250	
9073055: ECHO fingerklipper DTT-2100	9073057: ECHO 56V 2,3Ah, LBP-50-150; 9073058: ECHO 56V 4,5Ah, LBP-50-250	
9073056: ECHO plæneklipper DLM-5100SP	9073058: ECHO 56V 4,5Ah, LBP-50-250 (plæneklipperen kan køre på 1 ell. 2 batterier)	
9073061: ECHO motorenhed DPAS-2600	9073057: ECHO 56V 2,3Ah, LBP-50-150; 9073058: ECHO 56V 4,5Ah, LBP-50-250	